

TABLE OF CONTENTS
MEMBRANE BIOREACTORS (MBRs)

	Page
OBJECTIVES.....	vi
USES OF THIS MANUAL	vii
INSTRUCTIONS TO PARTICIPANTS IN HOME-STUDY COURSE.....	viii
SUMMARY OF PROCEDURE	viii
WORDS	xiii
ACRONYMS	xviii
LESSON 1	
1 MEMBRANE BIOREACTOR (MBR) OVERVIEW	1
1.0 What Is a Membrane Bioreactor (MBR)?	2
1.1 MBR Layouts	3
1.10 Sidestream Layout	4
1.11 Submerged Layout.....	4
1.2 MBR Technologies	4
1.3 MBR Advantages and Limitations	7
2 MBR FACILITIES.....	7
2.0 Headworks	7
2.1 Biological Nutrient Removal Basins	8
2.10 Anoxic Zone.....	8
2.11 Aeration Zone	8
2.2 Membrane Zone.....	9
2.3 Permeate.....	9
2.4 Disinfection	9
2.5 Solids Treatment.....	10
DISCUSSION AND REVIEW QUESTIONS.....	10
LESSON 2	
3 OPERATION OF THE MBR PROCESS	11
3.0 Pretreatment.....	11
3.00 Hydraulic Loading.....	11
3.01 Influent Screening	11
3.02 Pretreatment for Fats, Oils, and Grease (FOG)	11

3.1	Biological Nutrient Removal	11
3.2	Membrane Clogging and Fouling.....	12
3.3	Cleaning	14
3.4	Foaming.....	14
3.5	F/M Ratio.....	15
3.6	Membrane Integrity	16
3.7	Biological Operation and System Failure	17
3.8	Process Control and Monitoring Guidelines.....	17
3.9	MBR Failure Modes.....	17
3.10	Laboratory Testing	17
3.11	Typical Effluent Quality.....	17
	DISCUSSION AND REVIEW QUESTIONS.....	19
	LESSON 3	
4	PROCESS CONTROL.....	21
4.0	SCADA Systems	21
4.1	Controllers.....	21
4.2	Control Functions.....	21
4.3	Monitoring Functions.....	21
4.4	Data Logging Functions.....	22
4.5	Alarm Functions	22
4.6	Diagnostic Functions	22
4.7	Remote Telemetry Units	23
4.8	Operator Interfaces	23
5	MAINTENANCE.....	24
5.0	Computer Maintenance Management System (CMMS).....	24
5.1	Scheduled Maintenance	24
5.2	Critical Assets.....	25
5.3	Failure Consequence Analysis.....	25
5.4	Troubleshooting.....	34
	DISCUSSION AND REVIEW QUESTIONS.....	34
	LESSON 4	
6	MBR START-UP AND COMMISSIONING.....	37
6.0	Critical Elements.....	37
6.1	Start-Up Coordination.....	37
6.2	SCADA System Implementation.....	37
6.3	Equipment Verification	39
6.4	Laboratory Setup	39

6.5	Equipment and System Testing.....	39
6.50	Equipment Demonstration Testing.....	39
6.51	Plant Commissioning Testing.....	39
6.52	Process Commissioning Testing.....	40
6.6	Plant Operations Standards Development	40
6.7	O&M Staff Training.....	40
6.8	O&M Documentation (Operations Guide).....	40
7	MBR PLANT SAFETY.....	41
8	ADDITIONAL READING.....	41
	DISCUSSION AND REVIEW QUESTIONS.....	42
	SUGGESTED ANSWERS	42
	COMPREHENSIVE REVIEW QUESTIONS AND SUGGESTED ANSWERS.....	45
	SUBJECT INDEX.....	53

SUBJECT INDEX

A

Advantages of MBRs, 7
 Aeration zone, 8–9
 Alarm functions of SCADA systems, 22
 Alarms
 anoxic mixer failure, 35
 effluent pumps fail to start, 36
 effluent pump shut down, 35
 high level in process trains, 35
 influent pump fails to start, 35
 influent pump station fails to start, 36
 influent pump station high level, 35
 influent screen high level, 35
 low DO, 36
 low level in process trains, 35
 low pH on influent flow, 35
 membrane blower fails to start, 36
 permeate pump failure, 36
 process blower fails to start, 36
 RAS pump failure, 36
 train shut down, 36
 Alkalinity, consumption of, 12
 Ammonification, 8
 Anoxic zone, 8
 Assets, critical, 25

B

Backwashing, 11
 Bardenpho process for biological nutrient removal, 8
 Barriers to the use of recycled water, 1
 Bar screens, 11
 Biological nutrient removal, 8–9, 11–12
 Brown foam and F/M ratio, 15, 16
 Brush cleaning of screens, 11

C

Chemical clean-in-place method, 14
 Chemicals for cleaning membranes, 14
 Chemical wastestream from cleaning, 14
 City of San Diego's Advanced Water Treatment Demonstration Plant, 1
 Cleaning membranes, 14
 Clogging, 12, 13
 CMMS (computer maintenance management system), 24

Commissioning and start-up of MBRs, 37–41
 Computer maintenance management system (CMMS), 24
 Consequence of failure, 25–33
 Control functions of SCADA systems, 21
 Controllers, 21
 Conventional activated sludge (CAS) process used by MBRs, 5
 Coordination, start-up, 37
 Cost-effectiveness of an MBR system, 24

D

Data logging functions of SCADA systems, 22
 Denitrification, 8
 rates of, 12
 Design features to reduce foaming, 16
 Diagnostic functions of SCADA systems, 22–23
 Disinfection, 9–10

E

Effluent quality, 17, 19
 Effluent turbidity, permit requirement, 26
 Endogenous denitrification, 8
 Endogenous respiration, 8
 Energy costs of MBRs, 7
 Equipment and system testing, 39
 Equipment demonstration testing, 39
 Equipment verification, 39
 Excessive foaming and its impact, 14
 External layout MBRs, 3, 4
 Extracellular polymeric substances (EPSs), 11, 14

F

Facilities, MBRs, 7–10
 Failure, system, 17
 Failure consequence analysis (FCA), 25–33
 Failure modes, MBR, 17, 18
 Fats, oils, and grease (FOG), pretreatment for, 11
 Federal Communications Commission (FCC), 23
 Filamentous bacteria, 12, 14
 Filter papers, 16
 F/M ratio, 15
 Foaming, 14–16
 FOG (fats, oils, and grease), pretreatment for, 11
 Fouling, 12, 14

54 Membrane Bioreactors

- G**
- (NO LISTINGS)
- H**
- Headworks, 7
HMIs (human machine interfaces), 23
Hydraulic loading, 11
Hydrolysis, 8
- I**
- Influent screening, 11
Internal layout MBRs, 3, 4
International Electrotechnical Commission (IEC), 21
Inventory of spare parts, 24
- J**
- (NO LISTINGS)
- K**
- (NO LISTINGS)
- L**
- Laboratory setup, 39
Laboratory testing, 17, 19
Layouts of MBRs, 3–4
Limitations of MBRs, 7
- M**
- Maintenance cleaning, 14
Maintenance management, 24
Maintenance of MBRs
 assets, critical, 25
 CMMS (computer maintenance management system), 24
 consequence of failure, 25–33
 failure consequence analysis (FCA), 25–33
 scheduled maintenance, 24
 troubleshooting, 34, 35–36
Mechanical equipment list (MEL), 39
Membrane clogging and fouling, 12, 13, 14
Membrane integrity, 16
Membrane life, 24
Membrane permeability, 17
Membrane technology used by MBRs, 5
Membrane zone, 9
Mixed liquor recycle rate, 12
MLSS concentrations in MBRs, 17
- MMIs (man-machine interfaces), 23
Modified Ludzack-Ettinger (MLE) designs for biological nutrient removal, 8
Monitoring functions of SCADA systems, 21
Monitoring guidelines, 17
- N**
- Nitrification, 8
 rates of, 12
Nitrobacter bacteria, 8
Nitrosomonas bacteria, 8
Nocardia, 12
- O**
- O&M (operation and maintenance) documentation, 40
O&M (operation and maintenance) staff, 37
 training of, 40
Operation of the MBR process
 biological nutrient removal, 11–12
 cleaning membranes, 14
 clogging, 12, 13
 effluent quality, 17, 19
 failure, system, 17
 failure modes, 17, 18
 F/M ratio, 15
 foaming, 14–16
 fouling, 12, 14
 laboratory testing, 17, 19
 membrane integrity, 16
 monitoring guidelines, 17
 pretreatment, 11
 process control guidelines, 17
Operations guide, 40
Operator checklists (OCLs), 40
Operator interfaces (OIs) for SCADA systems, 23
Overaeration, 12
- P**
- Perforated-plate (circular opening) screens, 11
Permeate, 4, 9
Permit requirement
 effluent turbidity, 26
 high pH, 29
 low pH, 29
pH
 control of, 12
 permit requirement for, 29
Plant commissioning testing, 39
Plant operations standards development, 40
Plant safety, 41

PLCs (programmable logic controllers), 21
 Pretreatment, 11
 Preventive maintenance (PM) procedures, 40
 Process commissioning testing, 40
 Process control, 21–23
 Process control guidelines, 17, 19
 Process strategies, 16
 Programmable logic controllers (PLCs), 21
 Public perception of recycled water, 1

Q

(NO LISTINGS)

R

Ragging, 11, 13
 Recovery cleaning, 14
 Recycled water, barriers to the use of, 1
 Recycle rate of mixed liquor, 8
 Remote (or radio) telemetry units (RTUs) used by SCADA systems, 21, 23
 Return activated sludge (RAS) rate, 12

S

Safety, 41
 SCADA systems
 alarm functions, 22
 control functions, 21
 controllers, 21
 data logging functions, 22
 diagnostic functions, 22–23
 implementation, 37
 layout, 22
 monitoring functions, 21
 operator interfaces (OIs), 23
 programmable logic controllers (PLCs), 21
 remote (or radio) telemetry units (RTUs), 23
 Scheduled maintenance, 24
 Screening, influent, 11
 Screen washing, 11
 Shock loads, 5
 Sidestream layout MBRs, 3, 4
 Sludge bulking, 14
 Solids retention times (SRTs), 17
 Solids treatment, 10

Spare parts inventory, 24
 Staff training, 40
 Standard operating procedures (SOPs), 40
 Start-up and commissioning of MBRs, 37–41
 Start-up coordination, 37
 Submerged layout MBRs, 3, 4
 Surface fouling, 14
 System failure, 17
 System testing, 39

T

Technologies, MBR, 4
 Temperature, 12
 Testing during commissioning and start-up
 equipment and system, 39
 equipment demonstration, 39
 plant commissioning, 39
 process commissioning, 40
 system, 39
 Training of staff, 40
 Transmembrane pressures (TMPs), 16
 Troubleshooting MBRs, 34, 35–36

V

VDTs (video display terminals), 23
 VDUs (video display units), 23

W

Wastewater treatment process strategies, 16
 Wedge-wire screens, 11
 White foam and F/M ratio, 15

X

(NO LISTINGS)

Y

(NO LISTINGS)

Z

(NO LISTINGS)